



**Notes**

1. The reglet should be a minimum of 8" from the finished roof surface.
2. Ensure reglet is blown clean prior to applying sealant.
3. The Flex Modified membranes may be applied in hot asphalt or Flex's Cold Adhesive. Consult Technical Data Sheets for specific information as well as priming requirements.

Flex SBS Modified Roofing Systems

**REGLET  
COUNTERFLASHING**

CONVENTIONAL ROOFING ASSEMBLY

Scale: N.T.S.

Plot: 1:5

Issued: 08/07

Revision: KF

**FLMB-3E02**

Flex Membrane International, Inc.  
2670 Leisz's Bridge Rd. Suite 400  
Leesport, PA 19533  
800-969-0108  
www.flexmembranes.com