



Notes

1. Fasten the metal flashing to the wood blocking in a staggered pattern. Frequent fastening will reduce thermal movement.
2. Ensure deck slopes to drain, scupper or eavestrough on perimeter.

Flex SBS Modified Roofing Systems

ROOF EDGE

CONVENTIONAL ROOFING ASSEMBLY

Scale: N.T.S.

Plot: 1:5

Issued: 08/07

Revision: KF

FLMB-5E02

Flex Membrane International, Inc.
 2670 Leisch's Bridge Rd. Suite 400
 Leesport, PA 1933
 800-969-0108
 www.flexmembranes.com