



NOTES:

1. TEMPERATURE OF PIPE MUST NOT EXCEED 120° F (49° C).
2. SEALANT POCKET TO BE MINIMUM 1" (25 mm) FROM PENETRATION ON ANY SIDE.
3. APPLY PRIMER TO PENETRATIONS AND FLEX FLASHING/SEALANT POCKET PRIOR TO FILLING WITH MOLDED POCKET SEALANT.
4. MOLDED POCKET SEALANT MUST COMPLETELY FILL SEALANT POCKET AND MUST BE CROWNED TO PREVENT PONDING OF WATER.

APPLY HEAT TO BASE FLANGE OF FLEX SEALANT POCKET AND FORM BY HAND PRIOR TO HOT AIR WELDING

TPO 5.04

FLEX TPO PITCH POCKET