



NOTE: PREFABRICATED PIPE FLANGES MAY NOT BE VERTICALLY CUT AND WELDED BACK TOGETHER. IF FLANGE CANNOT BE SLID OVER THE TOP OF THE PIPE, USE METHOD AS DESCRIBED IN CODE 3.2 . COVER ANY ASPHALT RESIDUE ON PIPE WITH ALUMINUM TAPE PRIOR TO INSTALLING MEMBRANE.

TITLE		PREFABRICATED PIPE BOOT	
NAME		DETAIL NO. 4.60	
DRAWN BY:	KF	DATE:	10/2009
APPLICABLE TO ALL FLEX PVC			
MECHANICALLY FASTENED SYSTEMS			
FLEX MEMBRANE INTERNATIONAL		2670 LEISCZ'S BRDIGE RD. LEESPORT, PA 19533 800-969-0108 FlexRoofingSystems.com	