



NOTE:
 WHEN SELVEDGE EDGE OCCURS ON FASCIA SIDE OF
 NAILER, NAIL THROUGH THE FLEECE BACK OF THE
 MEMBRANE ONLY.

EXPOSED FACE DIMENSION GREATER THAN 3" REQUIRES
 A CONTINUOUS CLEAT SAME GAUGE AS FACE METAL.

- CONTINUOUS CLEAT NOT SHOWN FOR CLARITY.

| | |
|-----------------------------------|---|
| TITLE | |
| Flexclad Perimeter Edge Metal | |
| NAME: | |
| DETAIL NO. 1.10 | |
| DRAWN BY: | DATE: |
| KF | 07/2007 |
| APPLICABLE TO FLEX ADHERED | |
| SYSTEMS | |
| FLEX MEMBRANE INTERNATIONAL | 2670 LEISCZ'S BRIDGE RD. LEESPORT, PA 19533 800-969-0108 www.flexmembranes.com |